


ONLINE OWNERS MANUAL

LINK 2000-R IDEAL REGULATOR OPTION



INSTALLERS!!! THIS DOCUMENT IS IMPORTANT FOR OPERATION, PLEASE LEAVE IT WITH THE OWNER!!!

The **LINK 2000-R** is an integrated battery monitor, inverter/charger control, and advanced alternator regulator. This manual only pertains to the alternator regulator features. All other features and functions are described in the **LINK 2000** Owners Manual (Part # 890024). You must be familiar with that manual before using the **LINK 2000-R**.

**For use only with externally regulated
"P" Field type alternators.
See Required Reading page 8.**

FAST START: For installation details skip to the Required Reading section on page 8. Please read manual prior to using.

All warranty issues must be resolved through Heart Interface or Cruising Equipment Co. Please do not return to the retailer, or route warranty issues through the retailer.




Mfg. by **Cruising Equipment Co.** 6315 Seaview Ave. NW Seattle, WA 98107 (206) 782-8100 1

21440 68th Ave. So. Kent, WA 98032
(206) 872-7225 Toll Free 1-800-446-6180


TABLE OF CONTENTS

Front Panel and Status Lights	Page 3
How the LINK 2000-R Charges	Page 4-5
Equalizing Cautions!	Page 6
Special Set Up for the LINK 2000-R	Page 7
Required Reading	Page 8
Wire by Wire Instructions	Page 9-14
Standby Regulators	Page 14
Trouble Shooting Flow Chart	
Wiring Diagrams	

 The Helping Hand is used to draw your attention to very important sections of this manual or to indicate items of special interest. Please take the time to read these sections.

FRONT PANEL AND STATUS LIGHTS

The front panel operation of the **LINK 2000-R** is exactly the same as described in the **LINK 2000** owners manual with the exceptions noted below.



Charge Cycle status lights indicate which cycle the regulator (and or the charger) is in. The AC light will be off if there is no AC input and therefore no charger operation.

Selecting TIME when the alternator regulator is operating displays the alternator output current. The current is displayed with an "A" preceding the value.

FRONT PANEL SWITCHES

The operation of the front panel is the same as the **LINK 2000** with the exception of the **TIME** switch. When the alternator regulator is on (REG ON energized) and **TIME** is selected, the alternator current is displayed. It is preceded with the character "A". For example an alternator current of 100 Amps would be displayed as **A 100**.

CYCLE STATUS LIGHTS

The Charge Cycle status lights on the front of **LINK 2000-R** indicate which cycle the alternator regulator is in during charging. The meaning of the lights is the same as described in the **LINK 2000** installation manual. The only difference is that when there is no AC power available, and the regulator is turned on, the cycle lights indicate the charge cycle for the alternator regulator. If AC power is available, the charger is turned on, and the alternator is also charging the battery, the cycle lights indicate the cycle of both the charger and the alternator regulator.

STATUS: AC IN CHARGE ACCEPT FLOAT

AC IN: Green LED on when AC is present.

CHARGE: Red LED on when charger is in bulk Charge mode.
Flashes Red when charger is in Equalize mode.

ACCEPT: Orange LED on when charger is in Acceptance mode.

FLOAT: Green LED on when charger is in Float mode.

HOW THE LINK 2000-R CHARGES

 See page 18 of LINK 2000 manual for details of the Ideal Charge Curve.

The LINK 2000-R uses our **Ideal Regulator Output Module** to control the alternator to conform to the Ideal Charge Curve's four defining cycles; Charge, Acceptance, Float, and Equalize. The following discusses details of each of the cycles.

NOTES: 1) **Terminal number references are for the Regulator Terminal Board.**
 2) **Voltage values given for 70°F and liquid lead acid batteries.**

CYCLE
 STATUS
 L.E.D.

TURNING THE REGULATOR ON

The regulator is turned on by supplying 12V to the REG ON (Brown wire) terminal. It must be on only when the engine is running. See Page 12.

DELAY START-UP

Behavior: No Output on the Field Terminal (Blue wire).

Two second delay allows time for the engine to start.

RAMPING UP

Behavior: Output of Alternator increases over a 20 second period.

Ramping up the alternator output avoids shock-loading the belts with full alternator output. The output on the FIELD terminal is increased over a 20 second period until the Alternator Current Limit (Default Value 100A) is reached. The Charge Cycle now begins

CHARGE CYCLE

Behavior: Alternator at max and Battery Voltage is increasing.

The Charge Cycle insures fast charging without overloading the alternator. The Alternator Current limit will not be exceeded. The FIELD output is varied to hold the alternator at its current limit until the Charged Voltage is reached. When The Charged Voltage has been attained by either battery #1 or #2, the Acceptance Cycle begins.

ACCEPTANCE CYCLE

Behavior: Battery Amps falling, Voltage at 14.4V (Voltage depends on ambient temperature setting).

The Acceptance Cycle guarantees thorough charging by continuing to charge the battery until the charging current becomes a small percentage of battery capacity (2%). The alternator output is varied to maintain the battery at the Acceptance Voltage. During the Acceptance Cycle the alternator current limit will not be exceeded, even if a heavy load is placed on the system.

When the batteries have reached the Acceptance Voltage and the current is below 2%, the Acceptance Hold Cycle begins. If the Acceptance Cycle has lasted 3.5 hours, the Float transition cycle begins, even if the charged parameters have not been met. If the voltage of the batteries falls below the Acceptance Voltage for more than 2 minutes, the charge cycle starts again.

RED
 L.E.D.
 ON

YEL-
 LOW
 L.E.D.
 ON

YEL-
LOW
L.E.D.
ON

ACCEPTANCE HOLD CYCLE

Behavior: Voltage at 14.4V. Battery Amps below 2%;

The Acceptance Hold Cycle insures that the battery has accepted as much charge as it can. During the Acceptance Hold cycle the Charged Voltage is maintained and charging current is monitored. Both the Charged Voltage and the Charged Current % must continue to be satisfied for 10 minutes for the Acceptance Hold Cycle to end. The Acceptance Hold Cycle is also terminated after 20 minutes from its beginning even if the battery current has not stayed below the Charged Current for the entire time.

If the voltage of the batteries falls below the Charged Voltage for more than 2 minutes the charge cycle starts again.

GREEN
L.E.D.
ON

FLOAT TRANSITION CYCLE

Behavior: Battery Amps below 2%; Voltage is falling from 14.4V to 13.5V.

The Float Transition Cycle is intended to provide continuous alternator output during the cycle change from Acceptance to Float. Avoiding an abrupt transition between these voltages insures that electronic tachometers supplied from the alternator continue to work during the transition.

Once the Float Voltage value is reached, the Float Cycle begins.

FLOAT CYCLE

Behavior: Battery Amps below 2%, Voltage constant at 13.5V.

During the Float cycle the Float Voltage is maintained. The alternator will supply up to its current limit to maintain the Float Voltage.

RESTARTING THE CHARGE CYCLE

MANUALLY: The Ramp Up Cycle may be manually restarted by turning off the REG ON terminal and turning it back on again.

AUTOMATICALLY: The Charge Cycle is automatically restarted if the voltage of the battery being charged drops 0.2V below the Float Voltage (0.3V when charging with the inverter/charger) for more than 2 minutes.

RED
FLASH
L.E.D.
ON

EQUALIZE CYCLE

Behavior: Battery Amps constant at 4%, (16A max) Voltage is rising to a maximum of 16.0V. (Limited to Acceptance voltage for Gelled Batteries.)

To start the Equalize Cycle press the **SET UP BUTTON** for five seconds until the LED begins to flash. Now press both the **VOLTS** and the **A HRS BUTTON** simultaneously. Hold them both down for five seconds until the Red CHARGE LED begins to flash and the "E" in the display goes out. To terminate the Equalize Cycle and force the system into the Float mode repeat same procedure. The cycle automatically terminates after 3.5 hours initiation or when the current drops to 2% of capacity at 16.0V. (Equalize terminated in eight hours if using the Freedom charger.)

The Equalize Cycle is a controlled overcharge to remove Lead Sulfate which is not removed during normal charging. Liquid batteries should be Equalized every 30 days when in cycling service.

EQUALIZING CAUTIONS!

Turn off sensitive electronics before Equalizing !!!

Equalizing causes the battery to gas. You should check the battery electrolyte before and after equalization. Do not over-fill before equalization as the electrolyte may expand and cause it to flow over the tops. You should be present during this type of charging. Hydrogen and Oxygen gas is generated during equalization!! Make sure there is adequate ventilation.

Batteries should not be equalized every charge/discharge cycle. Normally, the battery is cycled between 50% charged and the 85% to 95% charged level reached by the normal Charge and Acceptance cycle. Every 30 days, though, the batteries should be equalized to regain full capacity and extend life.

To Equalize, first go through a complete Charge and Acceptance Cycle. Check the electrolyte level but do not overfill. Re-check and top off the electrolyte **after** Equalizing.

Remember, Equalizing is constant current charging with a small regulated current that allows a higher maximum voltage. The goal is to use a small current, not a high voltage.

Equalizing and Gelled Batteries

Gelled batteries are not normally equalized. However, if the battery has been severely discharged, the voltage of the battery may easily reach the Acceptance level with a very small current. In fact, the current may be less than the 2% required to terminate the Acceptance Cycle. This can cause the system to believe that the battery is full and switch to the Float mode. Equalization may be the only way to get the battery to accept a charge. Be sure that the battery TYPE # is set to #2 before using this cycle on gelled batteries. The equalization **voltage is limited to the Acceptance level** but the cycle lasts for 3.5 hours. (Eight hours if using the Freedom charger.) Please consult your battery manufacturer regarding the appropriateness of this cycle for their batteries.

SPECIAL SET UP FOR LINK 2000-R

The following is a list of special set ups that may be necessary to tailor the **LINK 2000-R** to your system. Please see Pages 10-13 of the **LINK 2000** Owners Manual for details on how to use the **FUNC** mode.

F10 - ALTERNATOR CURRENT LIMIT

DEFAULT = 100 RANGE = OFF, 30 - 220 AMPS STEP = 10 A

This function is only used with the Link 2000-R (Alternator Regulator Model). It sets a safety current limit for the alternator. This limits the maximum amount of current that the alternator can ever deliver. This value is reset to 100Amps in the event of a reset to factory default values.

 **CAUTION: OFF defeats this safety feature and the alternator will be ran at full output until the Acceptance Voltage is reached.**


F11 - BATTERY #2 USED FOR CONTROL

DEFAULT ON = BATTERY #2 USED FOR CONTROL
OFF = BATTERY #2 IS NOT USED FOR CONTROL.

This function is used to defeat Battery #2 as a part of the charger control function of the Link 2000. This is necessary for systems that have both 12V and 24V batteries. Battery #1 must be the battery that is used by the Freedom inverter (or charged by the alternator when controlled by the Link 2000R). You may also wish to use this function if the main house battery is substantially larger than a separate engine battery that is also monitored by the Link 2000. This will prevent the Link 2000 from making a premature transition to float based on the smaller engine battery meeting the charged parameters substantially before the house battery.

 **NOTE: Function F11 is not changed in a reset to factory default values. If you wish to change this function you must use the set up routine to change it.**

REQUIRED READING


- 1) See also the Required Reading section of the **LINK 2000** owners manual.
- 2) All wiring to the terminal boards should be #16 AWG (#14 may be used).
- 3)  The same cable recommended in the **LINK 2000** manual may be used for the **LINK 2000-R**. The wiring diagram is color coded to this cable.

CAUTION! YOU MUST READ THIS SECTION!

4) The **LINK 2000-R** is designed to replace external "P" type regulators. If your alternator is internally regulated, modification will be necessary. The **LINK 2000-R** is not designed to regulate N-type alternators, that is alternators that supply regulation by switching in the negative supply to the field. This includes most Japanese and internally regulated alternators. If these alternators are to be converted to external regulation **you must disconnect the internal regulator and the diode trio in the alternator**. This should be performed by a qualified alternator shop. **The warranty does not cover the alternator, batteries, or any other devices, or equipment in the system. An improperly converted alternator may cause damaging high voltages. Please be sure to check the regulation voltage during initial operation to verify that the LINK 2000-R is in control of the system.**

5) The **LINK 2000-R** can regulate alternators up to 230 Amps. The field current may not exceed 10 Amps total. (It can also regulate two alternators in parallel, charging the same battery, if they are the same size with a combined total capacity of less than 230 amps, and combined field current less than 10 Amps. If the alternators are on different engines you must install a normally open oil pressure switch, or a relay activated by the key switch, in series with the field of each alternator to avoid supplying field current to an alternator whose engine is not running.

6) The alternator shunt is in series with the alternator output and carries the full alternator current. The brass portions of the shunt are at +12V and should be protected from accidental contact to grounded objects or battery negative.

7)  If the alternator is being upgraded, with a high output alternator, you must increase the size of the alternator wiring. Use the table below to find the appropriate wire size. The total length of both the positive and negative runs must be measured.


ALTERNATOR MAXIMUM OUTPUT	CABLE SIZE (AWG)	
	10 FT OR LESS	11 TO 20 FT
35 A	#8	#8
60 A	#6	#4
75 A	#6	#4
100 A	#4	#2
130 A	#4	#1
170 A	#2	#1/0
200 A	#1	#2/0

8) Battery temperature must never exceed 120°F. We recommend a 110°F limit.


WIRE BY WIRE INSTRUCTIONS

Refer to the wiring diagram while using these instructions.


There are several components to **LINK 2000-R METERS**:




1) The **LINK 2000-R Meter**: Contains the micro-processor and display. The actual regulation program in the meter. It is terminated with a ribbon cable. It also has a phone jack for the remote cord to the inverter.



4) The **Monitor Terminal Board**: The wiring for battery monitoring terminates here. The ribbon cable from the meter plugs into this board. It also has a phone jack on it for the **Ideal Regulator** option.



2) The **Ideal Regulator Output Module**: Supplied with a harness that connects to the alternator. There is also a phone jack and plugs for the alternator shunt wiring and a red and a green LED used for trouble shooting.




5) The **Alternator Shunt**: Single 500A 50mV shunt used to measure current flowing out of alternator.



These two cords are not interchangeable.

6) **Four Conductor Phone Cord**: This 20' long phone cord connects the **LINK** to the inverter. This is the smaller of the two cords.



3) The **Battery Shunt**: Dual 500A 50mV shunt used to measure current flowing in or out of batteries.

7) **Eight Conductor Phone Cord**: This 20' long phone cord connects the Monitor Terminal Board to the Regulator Terminal board. This is the larger of the two phone cords.



Our Customer Service Manager says, "Be a genius, insure a successful installation by following our wire by wire instructions and please do the two progress and final start up tests."

BEGIN WITH THE MONITOR TERMINAL BOARD

Be sure the shunt is installed before proceeding.

The Monitor Terminal board should be secured behind or adjacent to the meter. It should be accessible and easy to see during hook up. The meter comes standard with an 18" ribbon cable. Ribbon cables 48" long are available.

Wiring is simplified by using our custom multiple conductor twisted pair cable available from your dealer. See LINK 2000 manual. If you supply your own cable we recommend 16 AWG. Larger is OK but not necessary. Do not use larger than #14 AWG, it will make terminating the wires difficult. Use twisted pairs where specified.

Begin hooking up from the bottom of the terminal strip toward the top.

Terminal #1 **BLACK WIRE** (AGND) is the Analog Ground. It is the reference for all measurements. It must be connected on the BSHG (Grounded) side of the shunt. The BSHG side of the shunt is the side opposite of the negative battery terminals. It must have a good connection to one of the two #10 screws on the top of the battery shunt.

Terminal #2 is not used.

Terminal #3 **LITE** turns on the display backlighting. It may be supplied from a switch that controls other instrument lighting or it may be connected to Terminal #4 if you wish the lighting to be on all the time. Set at the default lighting intensity the backlighting consumes about 8mA (.008A). If left on all the time it would use less than .2Ahrs per day.

Consider the options for the next wire.

Terminal #4 the **RED WIRE** (+12V) is the +12V supply. (In a 24V system supply with +24V.) The wiring diagram shows two options. The preferred option is to jumper together terminals #4 and #5 as shown. Wired this way, the meter cannot accidentally be de-powered. It has the disadvantage of always consuming a little bit of power from the #1 Battery. The meter consumes about 28mA (.028A). If left on all the time it would use about 0.7 A hrs per day.

If the system is left on for long periods, (long enough to significantly discharge the battery) with no charging sources, then you should consider the option shown with the dotted line. In this case the RED wire is not jumped to the BLUE but supplied from the common of the battery switch. (Be sure to install the 2A fuse as near the battery switch as possible.) Whichever battery is selected is the battery that supplies the power.

Caution: With this option if the battery switch is turned off the meter is de-powered and resets to zero, therefore battery switch must never be turned off except when leaving the system for a long period of time. When the system is returned to service you must resynchronize the meter by fully charging the battery.

Another option for the red wire is to install a separate on/off switch in it before it lands on the terminal board. Just remember to turn off the meter when leaving the system unattended.


Terminal #5 the **BLUE WIRE** (B1V) supplies Battery #1 Voltage for sensing. It should be supplied directly from Battery #1. Be sure to install the 2Amp fuse shown in the drawing as near the battery as possible.

Terminal #6 the **VIOLET WIRE** supplies Battery #2 Voltage for sensing. It should be supplied directly from Battery #2. Be sure to install the 2Amp fuse shown in the drawing.

 **Note: If only one battery is to be monitored jumper terminal #4 & #5 together.**

PROGRESS CHECK #1

The wires hooked up so far allow you to check the voltage monitoring functions. Install the fuse that supplies Terminal #4 and **carefully plug the ribbon cable into the Monitor Terminal board, make sure the pins are lined up correctly.**

 **From now on you may de-power the meter by unplugging the ribbon cable. If you remove the fuse that supplies terminal #4, +12V, with the ribbon cable plugged in you must be careful when reinstalling it. It must be a deliberate action. If the power to the meter is turned on and off in less than 5 second intervals it can cause the microprocessor to interrupt its initialization process. De-powering and re-powering by using the ribbon cable avoids this problem.**

Check each of the battery voltages. It is best to have a separate, accurate digital volt meter to compare the voltages shown against the actual battery voltage. They should be within a few hundredths of a volt. If they are not, check your voltage sense lead fuses


and fuse holders. Any problems must be resolved before proceeding. If you have questions call your dealer or us. Unplug the ribbon cable before proceeding, or remove the fuses in the wires to terminals #4, 5, & 6 before continuing.

The next four wires are for the battery shunts sense leads.

See Required Reading **LINK 2000** installation manual regarding the special care required in the installation of the shunts and their wiring.

Terminal #7 is the **GREEN WIRE** (B1SHG) which is connected to the **SMALL SCREW ON THE GROUND SIDE, OR LOAD SIDE**, of the battery #1 shunt (B1SHG). This wire must be located exactly as described to ensure accuracy of current measurements. The wires that run from the Battery shunt sense terminals to the **GREEN AND ORANGE** wires should be a twisted pair.

Terminal #8 is the **ORANGE WIRE** (B1SHB) which is connected to the **SMALL SCREW ON THE BATTERY SIDE** of the battery #1 shunt (B1SHB). This wire should be located exactly as described to ensure accuracy in current measurements.

 **NOTE: If only one current input is used, jumper terminals #7 & #9 together and terminals #8 & #10 together. This hookup will display the same current information for both the battery #1 and #2 selection.**


Terminal #9 is the **BROWN WIRE** (B2SHG) is connected to the **SMALL SCREW ON THE GROUNDED, OR LOAD SIDE**, of the battery #2 shunt (B2SHG). **SEE ABOVE CAUTIONS.**

Terminal #10 is the **YELLOW WIRE** (B2SHB) is connected to the **SMALL SCREW ON THE BATTERY SIDE** of the Battery #2 shunt (B2SHB). The **YELLOW** and **BROWN** wires should be a twisted pair. **SEE ABOVE CAUTIONS.**

PROGRESS CHECK #2

Plug the meter's ribbon cable back into the Monitor Terminal Board.

Now it is time to check the Battery Current function. Turn off all loads and sources. With everything off, the **LINK 2000-R** should read 0.0, -0.0, or no more than -0.1A. The meter uses less than 0.1A. If there is a larger current draw it normally means that not all the loads are turned off. There may be an alarm system, a clock, or other instrumentation that is left on all the time intentionally. That is OK, as long as you find each load and decide that it is an acceptable continuous current draw. Once your baseline current is known, remember it. If you cannot always turn off loads and reach that number you should find out why. Turn on various loads and make sure there is a minus sign in front of the display which indicates discharge. If the number has no minus sign and there are no charging sources on, it means that the battery shunt sense leads are reversed. If you have a problem call your dealer or us. The monitoring functions of the meter now are fully operational.


 The monitoring and inverter/charger functions of the **LINK 2000-R** may be operated independently of the alternator regulator functions. Unplug the phone cord between the Monitor Terminal Board and the Ideal Regulator Output Module to disable the regulator.


WIRING THE IDEAL REGULATOR OUTPUT MODULE

The Ideal Regulator Output Module may be located anywhere convenient to the alternator that is not subject to salt, or fresh water, spray. The components in this module have been coated to resist corrosion but are not immune to, nor warranted against, abuse. This module has on it the FET (Field Effect Transistor) that actually does the work of supplying power to the alternator field. While the reliability of this module is very high it also does all of the real work. The system has been designed with on site repairability in mind, a spare should be considered for long distance cruising.


The harness that is supplied with this module is a standard alternator harness. It is keyed so that it cannot be improperly plugged into the module. The colors mentioned below correspond to the color code of the wiring harness. There is also a 20' phone cord supplied to interconnect the Monitor Terminal Board and the Ideal Regulator Output Module. The following discusses each of the wires connected to the Ideal Regulator Output Module beginning from the left side of the module.

FIELD WIRE, BLUE: The BLUE FIELD WIRE is connected to the FIELD TERMINAL on the back of the alternator and supplies field current. The gray insulated plug connector may be plugged directly into standard high output alternators. (NOTE: The white wire that is stubbed out of the gray plug is for electronic tachometers and has no function related to alternator regulation.) If the plug will not fit into the alternator it may be cut off and the blue wire may be terminated with an insulated spade terminal or other appropriate connection for the alternator field terminal. The RED LED, on the Ideal Regulator Output Module, labeled CHG indicates field current is flowing **The RED LED glows more brightly as the alternator output increases.**

 **The RED LED should NOT be lit when the engine is off!!! If the RED LED is lit, and the green LED (labeled ON) is not lit, it is an indication that the FET is shorted. DO NOT OPERATE THE SYSTEM UNTIL THIS IS RESOLVED!**

 **CAUTION:** The gray plug will fit into the typical DELCO internally regulated alternator but the internal regulator must be disabled. **DO NOT attempt to use the Link 2000-R with an internally regulated alternator without modifying it to use external regulation!**

REG ON WIRE, BROWN: The BROWN REG ON WIRE turns on the regulator. It should be terminated on the recommended oil pressure switch, or some other switch (i.e. ignition switch or relay), that is hot (+12V) when the engine is running and off when the engine is off. If the system has an isolator or separate engine starting battery the BROWN WIRE should be supplied from a stable 12V source. This wire must not be connected to the oil pressure sensor for the oil pressure gauge or to the oil pressure switch for the alarm system. A separate N.O. Oil Pressure switch should be used. When this wire is energized the GREEN LED labeled ON is lit.

 **The GREEN LED must NOT be lit when the engine is off!!! If the regulator is left continuously ON it may destroy the Ideal Regulator Output Module, damage the alternator, discharge the battery, and cause system failure.**

+12V RED WIRE: The RED WIRE is the +12V supply. It is shown connected to the

alternator side of the alternator shunt (ASHA). Connecting it here insures a stable voltage with little voltage drop to supply the alternator field power. The 10 Amp fuse shown should be installed to protect the wiring.

 **If an isolator is used in the system this wire must be connected to the output side of the isolator.**

GND WIRE BLACK: The BLACK GND wire is the power ground. It is shown connected to the alternator ground.

ASHB WIRE GRN: The GREEN ASHB (Alternator SHunt Battery side) must be terminated on the small screw on the Battery side of the Alternator shunt. This wire must be connected exactly as shown.. Since this wire is at battery voltage it should be protected with a fuse at the shunt as shown; install the fuse after the wiring is connected. No other wires should be connected here.

ASHA WIRE YEL: The YELLOW ASHA (Alternator SHunt Alternator side) must be terminated on the small screw on the alternator side of the Alternator shunt. This wire should be connected exactly as described to ensure proper operation. Since this wire is at battery voltage it should be protected with a fuse at the shunt as shown; install the fuse after the wiring is connected. No other wires should be connected here.

FINAL TEST AND START UP

Do this test with the engine OFF!

This is the final checkout. Carefully plug the 8 conductor phone cord (the larger of the two phone cords) into the Monitor Terminal Board and the Regulator Output Module. Check the Battery Amps scale, you should see the same low number as in progress check #2. The green ON LED on the Output Module must be off.

Now we want to simulate the engine running, so turn on the regulator by turning the key switch to the on position, or if an oil pressure switch is used, jumper together its two terminals. For this test only we want to supply voltage to the REG ON terminal while the engine is off. The green ON LED should be on. The red Charge Cycle Status light on the Link 2000-R front panel should also be on. The red CHG LED on the Output Module, which indicates that field voltage is being supplied, should gradually increase in brightness during the next 30 seconds.

To verify that current is actually flowing into the alternator field use the LINK 2000-R to check the number of amps flowing from which ever battery has been selected by the main battery switch. You should see -3 to -5 amps of current flowing. This current is being supplied to the alternator field, and perhaps to other instrumentation that is also turned on with the key switch if you are not using an oil pressure switch. To verify that it is the alternator field consuming the current, turn off the power to the REG ON terminal and disconnect the FIELD (or REG OUT) wire from the alternator field. Repeat the test. The current should now be about 2 to 4 amps less than it was. This test assures you that the regulator is supplying the field current. Another easy way to test if the field is energized is to check the magnetism of the rotor by touching the end of the shaft with a screwdriver. Do it with the regulator turned on, and with it turned off, there should be a noticeable difference.



If you cannot pass this test do not start the engine!

See the Trouble Shooting Flow Chart.

It is now time to start up the engine and see how everything works. **For this test make sure the battery charger or any other sources are turned off.** Partially discharge the batteries (remove at least 20% of the capacity, it may take a few hours at a relatively high discharge rate). Start the engine and watch the battery voltage to see that it levels off at about 14.4 volts in the Acceptance Cycle. With the default values, when the battery current falls to about 4 amps (2% of the battery capacity) the regulator will shift into the Float Cycle and maintain the batteries at the Float voltage. Also check the alternator current by pressing the **TIME** button and using a millivolt meter to measure the voltage drop across the alternator shunt and comparing it to the reading on the **LINK 2000-R**. The millivolt reading multiplied by ten should about equal the **LINK 2000-R** reading. The alternator current measurement is inherently more inaccurate than the battery current measurement you may expect up to ± 3 amps error.

STANDBY REGULATORS

Part of Heart Interface and Cruising Equipment's power system design philosophy is to consider spares and backup systems before they are needed. We have designed the Ideal Regulator with this in mind. In our previous manuals we have shown a wiring diagram that shows how to wire a standby regulator and a switch to choose between the **LINK 2000-R** and a standby regulator. With the Ideal Regulator Output Module this is no longer necessary since its wiring harness is compatible with standard P-Field external regulators. Now you simply carry a spare regulator that is plug compatible and just unplug the Ideal Regulator Module and plug in your standby regulator. You may use a simple, adjustable, constant voltage regulator or we would suggest that you consider the Heart Incharge Regulator (Alpha Regulator from Cruising Equipment) which provides three stage charging, plug compatibility, and it is fully adjustable.